

FLOW RESTRICTOR REMOVAL

Step #1

Remove top and bottom mounts using set screws (#18 and #20). Remove unit from wall. Remove circlip, screen, and check valve from inlet fitting (#2). Reinstall unit.

Step #2

Remove restrictor in handshower (#10) and hose (#11) junction – Resembles check valve in step #1. Simply pull out. Needle nose pliers work best.

Step #3

Early production had cone-shaped restrictor in showerhead and shower arm junction – Remove restrictor. NOTE: Not all units have this restrictor.

